

# The LICCON- application programs for the LTM mobile cranes.

LICCON- application programs	LTM mobile cranes with the LICCON system													
	1030/2	1045/1	1055/1	1060/2	1080/1	1090/2	1100/2	1150/1	1160/2	1200/1	1250/1	1300/1	1500	1800
Safe load indicator/ SLI	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Configuration program with configuration image	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Operation program with operating image	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Telescoping program with telescoping image	● <sup>2)</sup>	● <sup>2)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>1)</sup>	● <sup>2)</sup>
Monitoring of supporting forces			○	○	○	○	○	○	○	●	●	●	●	●
Work area limitation			○	○	○	○	○	○	○	○	○	○	○	
Control- parameter- program			●	●	●	●	●	●	●	●	●	●	● <sup>3)</sup>	● <sup>3)</sup>
Test system	●	●	●	●	●	●	●	●	●	●	●	●	●	●
2D-work planner program <sup>4)</sup>	○	○	○	○	○	○	○	○	○	○	○	○	○	○

- standard
- option
- <sup>1)</sup> Telematik
- <sup>2)</sup> no „telescoping image“ but %-indication for T1, T2, T3 on „operating image“
- <sup>3)</sup> luffing winch of jib with graded speed (%)
- <sup>4)</sup> crane data diskette standard equipment, basic program optional